

National Unit Of Competency (Unit code and descriptor) and other Essential Education, Training and Evidence Requirements	Rail Safety Work Descriptor	Rail Labourer - Tie Renewal	Traffic Controller	Acceptable superceded units
TLIF2080 Safely access the rail corridor (4)		X	X	TLIF2080A, TLIF2080B, TLIF2080C
MTM Safety & Environmental Induction		X	X	
Medical Assessment Category 3		X	X	
CPCCWHS1001 Prepare to work safely in the construction industry		X	X	CPCCOHS1001A
TLIB1028 Maintain and use hand tools		X	X	TLIB1028A, TLIB2807B
TLID1001 Shift materials safely using manual handling methods		X	X	TLID1001A, TLID107C
TLIE1003 Participate in basic workplace communications		X	X	TLIE307C, TLIE1003A,
TLIF1001 Follow occupational health and safety procedures		X	X	TLIF1001A, TLIF107C
TLIF2010 Apply fatigue management strategies		X	X	TLIF2010A, TLIF1007C
TLIF2062 Apply awareness of safeworking rules and regulations		X	X	TLIF2062A, TLIF6207A
TLIU2008 Apply environmental procedures to rail infrastructure		X	X	TLIU2008A, TLIU809A
TLIC2059 Propel and Operate on-track Equipment		X		TLIC2059A, TLIC4109A, TLIC2041A
RIIWHS205D Control traffic with a stop-slow bat			X (1)	RIIOHS205A
RIIWHS302D - Implement traffic management plan (5)			X (1)	RIIOHS302A
RIICWD503d - Prepare work zone traffic management plan (5)			X (1)	RIICWD503A

**Notes**

- (1) This must be renewed every 3-years.
- (2) All Civil Plant (both high risk and non-high risk) and Civil Trades now fall under the ARA Matrix.
- (3) If a unit code or title that you hold differs slightly to that listed on the Matrix please contact [competencies@metrotrains.com.au](mailto:competencies@metrotrains.com.au) for clarification.
- (4) Safely access the rail corridor requires renewal every 2 years.
- (5) refer Vic Roads website for further guidance on traffic controllers.

**Matrix Code**

- X - Mandatory
- X - Optional